

Soft calender Voith Sulzer with accessories, Canada

List of the main components:


- double-nip soft calender consists of following parts
- main stands and connecting beams
- thermo-roll with bedding 1,016 mm (2 pcs), weight 25,3 t
- soft NIPCO roll 663 mm (2 pcs), weight 13,4 t
- guide and spreader rolls
- Calcoil boxes (2 pcs) for roll induction heating
- drive drive units for each group on the first and second nip
- 2 pcs of hydraulic aggregates
- oil heating station for the thermo-roll and filling tank
- hydraulic station for thermo-roll oil transport
- control panel
- electric distributor of the soft calender from the distributing centre
- other small accessories (bridges, staircases, handrails, covers, cardans, heating heads, piping, etc.)
- hard NIPCO roll 711 mm (from the roll storage)
- thermo-roll spare parts + bearing housings
- soft NIPCO spare parts 663 mm (2 pcs)
- ventilation
- operational documentation
- drawings form a part of the operational documentation





















PAPCEL, a.s. Uničovská 132, 784 10 Litovel, Czech Republic, e-mail: marketing@papcel.cz